HDMI Splitter

1×2

User Manual

1. INTRODUCTION

1×2 HDMI splitter distributes 1 HDMI source to 2 HDMI displays simultaneously.It offers HD video solution for super market; shopping mall; HDTV,STB,DVD,projector factory;data control center;information distribution;conference room presentation; education and training;corporation show room;home theater etc.

2.SPECIFICATIONS

Input Video Signal	0.5-1.0 volts p-p
Input DDC Signal	5 voltd p-p(TTL)
Max Single Link Range	1920×1080, 1080P
Output Video	HDMI 1.3+HDCP1.0/1.1/1.2
Resolutions DTV/HDTV	480p/576i/720p/1080i/1080p
HDMI Version	HDMI1.3
Operating Frequency	Up to 225MHz
EIDI Duration	4 Seconds
Power supply	DC 5V

3. CONNECTION

a) Connect the input source and output displays to the HDMI Splitter
b) Connect the DC 5V power supply to the splitter, Please kindly note that power supply with higher voltage may danage the splitter.
c) When input source and output displays are connecred and turnedon, the corresponding LED will light.

Attention: In order to protect the splitter and your devices, please makesure the splitter is powered off before you attach in or extract video source and displays.Please insert and extract HDMI cables gently.

4. BOX CONTENS

Item	Qty	Remark
HDMI splitter1×2	1PCS	
Power	1PCS	DC5V/1A
User Manual	1PCS	en

5. FAQ

A) The splitter doesn't appear to functioning.

Fistly, check if the LED lights, if the power supply is in condition and well connected.Secondly, make sure all cables are in good condition and well connected. Thirdly,make sure the length of the cables is with the maxmum supported length of this splitter. Listly, please try the input source to the display directly to see ifit display normally.

B) If the macimum resolution the two supported is not the same, what resolution be displayed?

The splitter will display at the lower one to both displays.